



APS Novastar ADVANCED ASSEMBLY SYSTEMS L SERIES AUTOMATED PICK & PLACE









Automated Pick & Place

System Features

- Placement rates up to 4800 cph
- Accommodates board widths up to 13.5". Board lengths range from 12" to 32" depending on model. (See Specifications)
- Placement accuracy to 0.001"*
- Vision system with fiducial correction, on-board dual function camera/computer color monitor
- Flexible feeder set-up allows easy interchange of electro-optical SmartCount™ tape, feeders
- On-the-fly component centering or optional touchless Cyberoptics[®] laser centering
- Resolution of 0.0000787" (2 microns) and accuracy to 0.001. Accurately places virtually all SMT components including discretes, SOICs, PLCCs, QFPs, and BGAs
- Capable of placing fine pitch components as low as 15 mil (0.381mm) and 0201s*

- Interchangeable tape, tube, bulk or tray feeders
- Fully self-contained all electric system. No shop air required
- Friendly, easy to use Windows® based software
- Automatic 4-position nozzle changer
- Fiducial correction
- Optional CAD transfer software.
- · Software for panelized boards
- Accessible, unobstructed work plateau for operator
- Heavy, welded, steel frame construction
- Full interlock system for operator safety
- Optional convenient SuperStrip™ feeders for short tape strips
- Optional fluid dispenser

L Series System Configuration

The L Series machines come in three basic sizes:

The **L40** has a maximum board size of 13.5" x 22" and a maximum capacity of 64 8 mm tape feeders.

The **L60** has a maximum board size of 13.5" x 32" and a maximum capacity of 96 8 mm tape feeders.

Options are available for both models.

Operation

Once a specific PCB is programmed, the machine automatically picks up each component from its designated feeder or tray, centers the part via laser Cyberoptics® or centering fingers, moves to the placement location via closed loop servo system, and accurately places the part. The feeders automatically position the next component for pick-up.

The automatic tool changer picks up the optimal nozzle for each particular component.

Feeders

on-the-fly places CSPs, micro BGAs and 15 mil pitch QFPs

Easy to change SmartCountTM electro-optical feeders available for tape, tube, bulk or matrix tray components.

Standard tape feeder sizes include 8 mm, 12 mm, 16 mm, 24 mm. 32 mm and 44 mm.

The L40 has a feeder capacity of 64, and the L60 has a feeder capacity of 96 positions. With the optional 12 position 8 mm bank feeders, capacity can increase by 50%, i.e. the model L60 would increase to a capacity of 144 8 mm tape feeders.


The vibratory feeder can handle loose and tube components.

Unique SuperStrip™ feeders are a convenient way to use short tape strips.

Feeder positions are pre-programmed for quick set-up.

APS Novasta

*with L-GS option (digital scales)



Model L60 showing easily accessible, unobstructed work deck

Laser Centering

The touchless Cyberoptics[®] centering option enables fast and accurate placement of the complete range of components.

Components

A wide range of components can be placed including 0201s, 0402s, 0603s, 0805s, 1206s, melfs, SO-28 to SO-8s, SOTs, SOICs, (fine pitch) QFPs, BGAs, large PLCCs, sockets and many others.

Software

The latest pentium PCs are included with these machines and the software is WindowsTM based to allow easy straightforward teach-in, requiring minimal operator training.

Multiple (panelized) boards can be programmed using the quick step-and-repeat feature. Using the dual function camera/ computer color monitor, standard PC keyboard and mouse, manual programming of a PCB is easy and intuitive.

Using CAD data from various layout systems will speed up the teach-in process for boards with many components.

Vision System

The teach-in camera magnifies the positions onto a dual use color monitor. Its built-in vision software provides fiducial correction of misregistered boards.

Fluid Dispenser

Computer controlled in 10 millisecond increments with separate interval/raise-lower speed allows solder paste or adhesive glue to be applied accurately prior to component placement. This time/pressure fluid dipenper has dispense rates up to 10,000 dots per hour.

Standard Features on all Models

- Automatic 4-position nozzle changer with 4 nozzles
- Friendly easy to use Windows® interface including software for panelized boards, self diagnostics, error recognition, fault monitoring and more!
- On-the-fly component centering using centering fingers
- Fiducial correction
- The latest pentium PC with flat screen monitor
- Positional resolution of 0.0000787" (2 microns) with closed loop micro servo driven motion control and digital encoders
- The component squaring station enables accurate placement of fine pitch components while protecting fragile leads from damage due to excessive force


Accessories/ Options

- Universal CAD transfer software
- Touchless Cyberoptics[®] laser centering system
- SuperStrip™ feeders for pickup from short tape strips
- SmartCount™ electro-optical tape feeders
- Tube and bulk feeders
- Matrix tray holders
- Bank Feeders (12 8mm lanes) offer a lower per lane cost and higher 8mm feeder capacity
- Automatic fiducial correction
- Fully computerized fluid dispensing system
- Micro nozzles or Multi-Micro nozzles for small components
- Touch screen with enhanced operator interface
- Cognex[®] vision assist placement models: LS40V & LS60V



Specifications

Max board area L60	
Max board area L40	
Max travel area L60 22"(X axis) x 32"(Y axis) (560 x 813 mm)	
Max travel area L40 22"(X axis) x 22"(Y axis) (560 x 560 mm)	
Z axis max travel	
Board thickness	
Typical verifiable placement rate	
Max placement rate 4800 cph	
Placement accuracy	
Fine pitch capability to 25 mil pitch (0.635mm), 15 mil pitch (0.381mm)***	k
Smallest component capability 0603 packages standard, 0201s***	
Largest component size	
Max no. of feeders (8mm tape)	
Max no. of feeders with L-GB-12 bank feeders 96 (L40), 144 (L60)	
Tape feeders	
Tube feeders (bulk also) 8, 10, 14, 18, 24, 32 mm (Manual freq. control)	
Matrix Tray Feeders with Board/Matrix tray holders	
Component orientation Ø-axis motion	
System dimensions L60 38" x 48" x 52"h (965 x 1219 x 1320 mm)	
System dimensions L40 38" x 38" x 52"h (965 x 965 x 1320 mm)	
Laser centering touchless Cyberoptics® laser	
Standard centering Centering fingers - 1 set mounted on head	
Weight L60	
Weight L40	
Weight L20	
Board holding Edge clamp w/optional board support tooling	
Data entry Coordinate entry, "teach" mode, CAD download	
Vision system Color CCD card camera	
Automatic 4 position Tool changer additional changer optional	
Operating system Microsoft® Windows®	
Dispenser option syringe holder type up to 10,000 dots/hr.	
Power 120 VAC, 50/60Hz, 220-240 VAC available	
Vacuum on-board compressor for nozzles	
Compressed air Shop air required for dispenser option only, 60 psi	
Low-force fine pitch squaring station (L-SQ) dual routines	
(not required with laser centering option)	
Automatic fiducial recognition Option	



Machines

MODEL L60 Auto pick & place (13.5 x 32" boards, 96 feeder positions) MODEL L40 Auto pick & place (13.5 x 22" boards, 64 feeder positions)

Machine Accessories/Options

L-NC4 Extra 4 position nozzle changer - for 8 total positions
L-CL Cyberoptics [®] centering laser
L-LD Liquid dispenser
L-GS Digital linear scale encoders
L-BHS Board support
L-UCT CAD editor software option
L-AFC Auto fiducial recognition
L-TS Touch screen with enhanced operator interface

Tape Feeders

L-T8 8 mm tape feeder - option
L-T8-0402 8 mm tape feeder - for 0402 or larger components - option
L-T8-0201 8 mm tape feeder - for 0201 or larger components - option
L-T12
L-T16
L-T24
L-T32
L-T44
L-GB-12 Bank feeder with 12 positions for 8 mm tapes - option

Vibratory Feeder Inserts

L-VF Vibratory tube/bulk feeder - option
L-VFI-1 Tube insert for SO8M, component width of 0.236" (6.0 mm)
L-VFI-2 Tube insert for SO14/16M, component width of 0.236" (6.0 mm)
L-VFI-3 Tube insert for PLCC84M, component width of 1.190" (30.2 mm)
L-VFI-4 Tube insert for SOP16M, component width of 0.311" (7.9 mm)
L-VFI-5 Tube insert for SOL28M, component width of 0.405" (10.3 mm)
L-VFI-6 Tube insert for SOW32M, component width of 0.480" (12.2 mm)
L-VFI-7 Tube insert for SOX40M, component width of 0.540" (13.7 mm)
L-VFI-8 Tube insert for SOY40M, component width of 0.567" (14.4 mm)
L-VFI-9 Tube insert for SOZ44M, component width of 0.630" (16.0 mm)
L-VFI-10 Tube insert for SOLJ32, component width of 0.331" (8.4 mm)
L-VFI-11 Tube insert for SOXJ44, component width of 0.441" (11.2 mm)
L-VFI-12 Tube insert for PLCC28M, component width of 0.490" (12.4 mm)
L-VFI-13 Tube insert for PLCC44M, component width of 0.690" (17.5 mm)
L-VFI-14 Tube insert for PLCC68M, component width of 0.990" (25.1 mm)
L-VFB-0305 Bulk insert for 0603 and 0805 components
L-VFB-0608 Bulk insert for 1206 and 1008 components
L-VFB-1012 Bulk insert for 1210 and 2512 components

Other Feeders*

L-MBH		Matrix t	ray	hold	ers	(set	of	2) - o	ption
L-SS-XX	Dual Lane SuperStrip ^T	[™] feeder	for	strips	s fro	m 1	" to	12"- 0	ption
	XX indicates tane v	width: 8	12	16	24	32	11	or 56	3 mm

Nozzles*

L-N025-030	Standard
L-N035-050	Standard
L-N050-080	Standard
L-N109-140	Standard
L-N187-218 Large nozz	le option
L-N281-312 Large nozz	le option
L-N016-020 Micro nozz	le option
L-N4X5-020 Multi micro nozz	le option

^{*}Custom options, nozzles and feeders available - contact factory.



Leasing Options Available...
For more information, phone us at +1-215-938-1000 or email us at info@apsgold.com

2840 Pine Road • Huntingdon Valley, PA 19006 • USA

^{**}Max. component depth to 0.500 inches including carrier

^{***}with L-GS option (digital glass scales)

^{† 30} mm square (1.18" square) max size with Cyberoptics® centering laser option